

G3TXQ Broadband HexBeam - spreaders



Note:

1. Each spreader is made from two 4m (4 section) fishing poles Shakespeare 1056-400 or equivalent
2. Cut off the plastic boss from 1D and 2D using a fine-tooth saw
3. Discard sections 1A, 2A and 2B - these are not needed
4. Insert 1B into 1C and pull tight
5. Insert 2C into 2D and pull tight
6. Push 1B/1C over 2C/2D
7. Push 1B/1C/2C/2D over 1D
8. Make sure all joints are tight, then cut 1B to give 135" total length